

- INSTALLATION INSTRUCTIONS - PORCELAIN ENAMELED STEEL BATHTUBS

A word of caution: This new fixture has a durable finish:
However, extra care should be exercised during
installation when rough handling and the danger
of dropped tools may cause damage.

1. Check the tub thoroughly for shipping damage. Report any apparent damage to the distributor that furnished the tub and request their advice on continuing with the installation.
2. Protect this bathtub during installation and construction by using this corrugated container as indicated. Cut along the dotted lines and place the corrugated protector over the top and front of the tub. The center cut out drops into the center of the tub.
3. After measuring the dimensions of the product, frame the construction area.
4. Place the tub in position and mark a joist so that a 2 x 4 stringer can be nailed in place. The stringer will be located under the flange against the wall. Nail in place the 2 x 4 support. Reposition the tub and check for level, both front to back and left to right.
5. Shimming the tub to achieve a good level may be necessary. Only small shims should be used in conjunction with the bathtub's own support pad. Note: There will be a small gap between the apron panel and the floor to allow for tile, carpeting, etc. Caulking could be used to seal this gap.
6. Overflow and drain assembly, faucet, and the shower head should be installed to the manufacturers specifications. Over tightening the drain can damage the tub.

CARE AND CLEANING

Clean with warm water, a soft cloth and a mild detergent.
NEVER use abrasive scouring powders, cleansers or pads.

Alternative cleaning method:

Use "ZUD" or "Barkeepers Friend". Wet area to be cleaned, sprinkle on cleanser, scrub with a non-abrasive brush. Rinse thoroughly with water and wipe dry.

