



















HARDWARE & PARTS PACKAGE LIST


A		1/4" x 1 1/4" Bolt	2 pcs
B		1/4" x 2" Bolt	4 pcs
C		1/4" Spring Washer	6 pcs
D		1/4" x 16mm Flat Washer	4 pcs
E		1/4" x 11mm Flat Washer	2 pcs
F		4mm Allen Wrench	1 pc
G		13mm Open Wrench	1 pc
H		Φ8 x 1 1/4" Screw	4 pcs
I		Φ3 x 5/8" Wood Screw	5 pcs
J		Back / Seat Frame	1 pc
K		Seat Cushion	1 pc
L		Arm (right & left)	1 Set
M		Wood Cap	5 pcs
N		Wood Hole Plug	5 pcs
O		Hydraulic Rod Assembly	1 pc
P		Swivel Base	1 pc
Q		Glue	1 pc



Desk Chair
Item#: 96033 / 96133

Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. To prevent scratches or damage, assemble the chair on a soft surface such as a blanket or carpet.

STEP 1




STEP 2

STEP 1 :

Assemble Arm to the Back Frame and Seat Frame. Connect the back end of the Arm to Back Frame as shown using the 1-1/4" long bolts (A), Spring Washers (C) and Flat Washers (E). Tighten finger tight only, until after next step.

Connect the front end of the Arm to the Seat Frame as shown using the 2" long bolts (B), Spring Washers (C) and Flat Washers (D).


Tighten all Bolts using the Allen Wrench (E). Apply a small amount of Glue around the Wood Hole plug and press into the hole in the Back Frame.



STEP 3 :


Turn the Seat Cushion (K) upside down and place it onto the corner of a table with the front edge facing inward. Carefully turn the assembled chair frame upside down and center it on the bottom side of the Seat Cushion. Attach the Seat Cushion using the 1 1/4" long Wood Screws (H) and your Phillips Screwdriver.

Securely hold chair to prevent it from falling off table.



STEP 4 :

Attach the Wood Caps (M) on top of each Leg of the Metal Base (P) using the 5/8" Short Wood Screws (I) and the metal plate across the bottom side. Use the Open Wrench (G) to tighten the casters into the metal base if necessary.



STEP 5 :

Insert the Hydraulic Rod into the Center hole in top of metal Leg Base, place the other 2 black plastic protective parts over the Hydraulic Rod in the order shown. Press the Chair Seat down onto the top end of the Hydraulic Rod.

Any chair equipped with casters should never be used on unprotected hardwood or vinyl flooring because damage to flooring could occur.